WESTON UNITED METHODIST CHURCH

HEATING/AIR CONDITIONING CONTROL - PASTOR'S STUDY

HEATING

For the winter-time, the switch at the end of the baseboard heater must be switched 'up', allowing the wall thermostat by the door to control the operation of the baseboard heater as one would expect.

COOLING

In the summer-time, the switch at the end of the baseboard heater should be switched 'down'. Also, the wall (heating) thermostat by the door should be turned all the way 'up' - to its highest setting. This provides power to the switch at the end of the baseboard heater which then diverts the power to the air conditioning unit. The controls on the through-the-wall air conditioner will operate the unit as expected.

a:\WUMC\Trustees\Manual\Heat-AC 7-2-97